


OP-9612 AIR BELT SANDER



REF. NO	PART. NO	DESCRIPTION	Q' TY	REMARK
※1	9612#01	GRINDING BELT (#100)	1	
※1A	9612#1A	GRINDING BELT (#80)	1	
※2	9612#02	IDLE PULLEY SUB ASSY (2A. 2B. 3)	1	
※2A	9612#2A	IDLE PULLEY	1	
※2B	9612#2B	BALL BEARING (684zz)	2	
※2C	9612#2C	SPACER	1	
3	9612#03	WASHER	1	
4	9612#04	IDLE PULLEY SHAFT	1	
5	9612#05	BRACKET	1	
※6	9612#06	TENSION BAR	1	
※7	9612#07	SET SCREW (M3x6)	1	
※8	9612#08	SET SCREW (M3x8) CROSS	1	
9	9612#09	SPRING (1x7. 2x6. 5)	1	
10	9612#10	SPRING PIN (3x10)	1	
11	9612#11	SPRING (1. 7x4x35. 5)	1	
12	9612#12	SHONE	1	
13	9612#13	SET SCREW (M4x8) CROSS	1	
14	9612#14	GUARD SUB ASSY A	1	
14A	9612#14A	GUARD BUSHING	1	
15	9612#15	HEXAGON SOCKET HEAD BOLT (5x15)	1	
16	9612#16	WASHER	1	
16A	9612#16A	HEXAGON SOCKET HEAD BOLT (6x20)	1	
17	9612#17	DRIVE PULLEY	1	
18	9612#18	HOUSING	1	
※19	9612#19	BALL BEARING R6ZZ	1	
20	9612#20	END PLATE B	1	
21	9612#21	SPACER (10x13x3)	1	
22	9612#22	SUNK KEY	1	

REF. NO	PART. NO	DESCRIPTION	Q' TY	REMARK
23	9612#23	CAP	1	
※24	9612#24	BALL BEARING (626zz)	1	
25	9612#25	END PLATE A	1	
26	9612#26	CYLINDER	1	
26A	9612#26A	PIN (ϕ 3x6)	1	
※27	9612#27	BLADE ASSY	5	
28	9612#28	ROTOR	1	
29	9612#29	THROTTLE LEVER	1	
30	9612#30	LEVER PIN	1	
31	9612#31	VALVE BODY	1	
32	9612#32	O-RING (P9)	1	
33	9612#33	O-RING (P9)	1	
34	9612#34	O-RING (P5)	1	
35	9612#35	VALVE STEM	1	
36	9612#36	O-RING (ϕ 3. 6x2. 4)	1	
37	9612#37	VALVE SPRING	1	
38	9612#38	DEFRECTOR	1	
39	9612#39	AIR INLET	1	
40	9612#40	TENSION BAR	1	
41	9612#41	SPRING	1	
42	9612#42	LEVER PIN (ϕ 2x6)	1	
43	9612#43	LEVER PIN (ϕ 5. 2x10)	1	
44	9612#44	DUST COVER	1	
45	9612#45	TENSINDLE	1	
46	9612#46	DEAD HANDLE	1	
47	9612#47	SPRING PIN (ϕ 3x15)	2	
48	9612#48	HEXAGON WRENCH KEY 4	1	
49	9612#49	HEXAGON WRENCH KEY 1. 5	1	

Remark:Ref No. or Part No. has been noted by ※ are not in warranty.

<http://www.onpin.com.tw>

DATE : B