


OP-9620 AIR BELT SANDER



REF. NO	PART. NO	DESCRIPTION	Q' TY	REMARK
※1	9620#01	TENSION BAR 10	1	
※2	9620#02	IDEL PULLEY ASSY	1SET	
2A	9620#2A	HEXAGON SOCKET HEAD BOLT	1	
2B	9620#2B	WASHER(M5)	1	
2C	9620#2C	E-CLIPER(ETW003)	1	
2D	9620#2D	IDLE PULLEY SHAFT	1	
2E	9620#2E	BALL BEARING	2	
2F	9620#2F	WASHER	1	
2G	9620#2G	HEXAGON NUT(M5)	1	
2H	9620#2H	IDLE PULLEY	1	
2I	9620#2I	WASHER	1	
3	9620#03	SPRING	1	
4	9620#04	FINGER PAD ASSY	1	
4A	9620#4A	TOOTHED LOCK WASHER (AW6)	1	
5	9620#05	HEXAGON SOCKET HEAD BOLT	1	
5A	9620#5A	CUP SPRING	1	
6	9620#06	HEXAGON SOCKET HEAD BOLT	1	
※7	9620#07	CRINDING BELT(#100)	2	
7A	9620#7A	CRINDING BELT(#80)	1	
8	9620#08	HEXAGON SOCKET HEAD BOLT	1	
8A	9620#8A	WASHER	1	
9	9620#09	DRIVE PULLEY	1	
10	9620#10	FLAT SHOE	1	
11	9620#11	HEXAGON SOCKET HEAD BOLT	1	
12	9620#12	DUST COVER	1	
13	9620#13	GUARD BODY	1	
14	9620#14	TENSION BAR	1	

REF. NO	PART. NO	DESCRIPTION	Q' TY	REMARK
15	9620#15	SPRING	1	
16	9620#16	LEVER PIN(ϕ 2*6)	1	
17	9620#17	LEVER PIN(ϕ 2*8)	1	
18	9620#18	HOUSING	1	
19	9620#19	BALL BEARING	1	
20	9620#20	END PLATE A	1	
21	9620#21	SPACER 10*13*3	1	
22	9620#22	SUNK KEY 2*2.5*10	1	
23	9620#23	CAP	1	
24	9620#24	BALL BEARING	1	
25	9620#25	END PLATE A	1	
26	9620#26	CYLINDER	1	
※27	9620#27	BLADE ASSY	5	
28	9620#28	ROTOR	1	
29	9620#29	THROTTLE LEVER	1	
30	9620#30	LEVER PIN(ϕ 3*23)	1	
31	9620#31	VALVE BODY	1	
32	9620#32	O-RING (P9)	1	
33	9620#33	O-RING (11.89*1.98)	1	
34	9620#34	O-RING (P5)	1	
35	9620#35	VALVE STEM	1	
36	9620#36	O-RING(3.6*2.4)	1	
37	9620#37	VALVE SPRING	1	
38	9620#38	DEFRECTOR	1	
39	9620#39	AIR INLET	1	
40	9620#40	HEXAGON WRENCH KEY4	1	

Remark:Ref No. or Part No. has been noted by ※ are not in warranty.

<http://www.onpin.com.tw>

DATE : B